

WORLD CLASS
SUPERYACHT
LABORATORY
ANALYSIS



SPECTRO® | JET-CARE®

spectro-oil.com | jet-care.com



"Routine analysis and trending give an accurate insight into potential performance and reliability issues."



Maintaining the optimum condition of lubricating oils, hydraulic fluids, greases and fuels is critical to ensuring the efficient and safe operation of a vessel. That is well known and yet there is much more that analysis can provide as a predictive tool to avoid accelerated wear in engines and machinery and ultimately prevent failure, well before any other signs are evident.

Routine analysis and trending give an accurate insight into potential performance and reliability issues and allows precise programming of maintenance schedules to suit the vessel's operational cycle, negating downtime at inopportune periods and geographic locations.

Fluid analysis is also an essential tool during re-fit to ensure that optimum performance has been restored after repair and furthermore to identify wear situations which might only be able to be repaired in dry dock or refit. Classification Societies regularly defer extensive and invasive surveys, such as stern tubes and thrusters, if routine oil and fluid analysis is performed by a suitably qualified and accredited laboratory*.

Purchasing or selling a vessel requires a precise assessment of the vessel's mechanical condition by both buyer and seller. For the seller to endorse the pedigree of the vessel and for the buyer to confirm or refute the same. Historical maintenance records are, of course, important but a real time snapshot of mechanical condition can only be truly accurate through the use of spectrographic laboratory analysis of fluids. This gives a present and historical indication of potential problems that might pre-exist and manifest themselves after sale of the vessel.

Independent laboratory analysis is therefore the ultimate and effective security against engine and machinery malfunction, accelerated wear and failure.

QUALITY

Our unrivalled expertise, quality control and integrity are supported by industry recognised accreditation* that ensures each of our laboratories maintains the same exacting high standards.

UKAS (United Kingdom Accreditation Service) and SAS (Swiss Accreditation Service) verify that our laboratories comply with ISO/IEC 17025:2017, the testing and calibration laboratory standard. In addition, we hold Service Supplier Status for American Bureau of Shipping (ABS) and Lloyd's Register.



0261



1961



STS 6579



*The use of the UKAS/SAS marks does not imply that all activities are accredited by UKAS/SAS. Accreditation covers the laboratory activities in accordance with the schedule, which can be found on the Spectro | Jet-Care website.

ANALYSIS OFFERING

Analysis is performed from samples provided by the vessel, using easy to use sample kits that include the price of analysis. The kits include a sample pump to extract the fluid cleanly and directly to the bottle, labelling, and outer packaging to allow safe transit.




OIL ANALYSIS

Unscheduled downtime of critical equipment limits availability and therefore the profitability of the operator. Quality used oil analysis provides a core tool to monitor equipment condition with rapid turn times, coupled with clear and concise reporting, expensive downtime and repairs can be minimised and catastrophic failure avoided. Notwithstanding the downstream costs both reputational and in time of off hire/charter.



HYDRAULIC ANALYSIS

The regular sampling and testing of hydraulic fluids is key to ensuring critical control systems are kept in optimum perfect condition, as well as meeting safety standards. Regular testing of hydraulic fluid provides a clearer picture of system cleanliness and performance. Worthy of note is that even fresh hydraulic fluid straight from a drum can fail cleanliness tests and result in equipment failing to operate.



COOLANT ANALYSIS

Specific engines rely upon sealed coolant systems and these can be vulnerable to microbial contamination and coolant degradation with consequent and potentially damaging overheating issues. Furthermore, leakage can be identified through regular analysis.



FUEL ANALYSIS

Periodic monitoring of fuel tanks is fundamental to ensure that fuel cleanliness is maintained at all times and to identify where treatment is needed. Particularly now that the IMO 2020 regulations have caused supply chain stress for distillate fuel.

Water encourages the development of bacteria and fungi which could lead to blockages and consequent operational problems. The testing of samples for water content and microbiological growth of aerobic bacteria and viable fungal spores provide positive indication of fuel system contamination.

VERIFICATION OF BUNKERED FUEL

The consequences of off-spec fuel can be significant and not only in engine performance but downstream too with microbial contamination.

Of equal seriousness are the environmental and legal implications of a high sulphur content, notwithstanding the attendant issues that high FAME content can cause or the safety issues of low Flash Point fuel.

The Spectro | Jet-Care Fuel Verification Sample Kit has been designed purely to assist with obtaining fuel samples at the time of bunkering. Security tagged to avoid tampering one sample is analysed to verify and understand the quality and specification of the fuel taken onboard. Further samples are kept onboard for future testing if required.






"Maintaining the optimum condition of lubricating oils, hydraulic fluids, greases and fuels is critical to ensuring the efficient and safe operation of a vessel."



FIRE WATER MIST ANALYSIS

Fire suppression by water mist generation is an important safety factor onboard. New regulations insist upon mandatory testing of this water to identify elements that may cause dysfunction of the system when called to action during a fire.



GREASE ANALYSIS

Grease analysis is an important condition monitoring function as indications of advanced wear, overheating, grease degradation, contamination and bearing metal deposits can readily be identified. Equally where the wrong grease has been used, or indeed too much grease, this can be identified too.



DEBRIS & FILTER ANALYSIS

The analytical capabilities of Scanning Electron Microscopes (SEM), and powerful optical microscopes, are used for the in-depth examination of debris. Particles can be found within filters, on metallic wear debris detectors or during routine visual inspection of fluid test samples. By considering the type, form, quantity, size and condition of the particles we can make recommendations on the likely source of the debris. Early filter blockage happens for a reason – we can tell you why.



ANALYSIS KITS



OIL SAMPLE CASE



OIL RESTOCK KIT



HYDRAULIC FLUID SAMPLE CASE



HYDRAULIC FLUID RESTOCK KIT



FUEL VERIFICATION SAMPLE KIT




FIRE WATER MIST SAMPLE KIT




SINGLE HYDRAULIC KIT



SINGLE FUEL KIT



OIL EXTRACTION PUMP



ADAPTORS



LOGISTICS

Logistics are a vital aspect of any laboratory analysis program and the team at Spectro | Jet-Care are well aware that post Brexit this can cause challenges if customers are inexperienced in the correct procedures. Having addressed these issues and established the correct methodology and courier routes, the Spectro | Jet-Care logistics team can ensure swift passage without delay to any of our laboratories.



webECHO™

webECHO is a versatile online resource available 24/7/365 to manage your equipment, fleet data and access your latest reports and trends through a single portal. The integrated system allows you to download reports, view graphs, read the advice dialogue and analyse data in real time. It can also be run on a variety of mobile devices such as Apple and Android tablets and smartphones.

webECHO is available at no extra charge as part of our support service and is a convenient and user friendly way to manage your analysis results and trend monitoring.

REPORTING & TECHNICAL SUPPORT

Within two working days your results are reported either by email or can be accessed through our online portal, webECHO™. The analysis reports are provided in PDF format and show the equipment history which can be discussed further with our technical team, who not only understand laboratory analysis but marine equipment and vessel operation.

OIL ANALYSIS REPORT											
EARLY WARNING											
For the Attention of Laboratory Report Reference Laboratory Report Date Receipt Date 14-Jun-21 Sample Date 08-Jun-21 Sample Point 6 Comments Locate and eliminate source of WATER. Take check sample and monitor closely.											
Equipment Information Vessel # Description # Manufacturer Stern Thruster Gear Model # Serial Number # Customer Reference # Unique Code Oil Grade # Unit Life # Oil Life #											
Shell Omaha 150											
Sample Number 18 → 29 → 29 → 29 → 29 → 29 → 29 → 29 → 29 → 29 → 29 → 29 → Analysis Date 13-Jun-21 29-Jun-21 09-Feb-21 08-Mar-21 20-Mar-21 09-Apr-21 21-Apr-21 17-May-21 05-Jun-21 30-Jun-21 Sample Date \$ 04-Jun-21 23-Jun-21 30-Jun-21 25-Feb-21 18-Mar-21 05-Apr-21 15-Apr-21 04-May-21 20-May-21 08-Jun-21 Ticket Number \$ 154551 154554 154550 154552 175092 175084 175085 175087 175088 175090 Lab Reference SPM10814 SPM10240 IM22873 SPM10959 SPM106428 SPM106000 SPM10648 SPM107369 SPM107692 SPM10810 Unit Life \$ 2508 2508 2500 2500 2500 2500 2500 2500 2500 2500 Oil Life \$ 7 7 9 9 9 20 30 30 10 13 2 Oil/Fluid Added \$ - - 0 0 2 0 0 0 0 0 Sampling Point \$ drain value											
Physical Condition Appearance (N/A) - - - - - - - - - - NAS 1638 (M033) class - - - - - - - - - - ISO 4406 1993 (M033) >10µm - - - - - - - - - - PS 3 - 15 µm (M033) per 200ml - - - - - - - - - - PS 12 - 25 µm (M033) per 200ml - - - - - - - - - - PS 50 - 100 µm (M033) per 200ml - - - - - - - - - - PS 100+ µm (M033) per 200ml - - - - - - - - - -											
Opinions and interpretations included in this report are outside the scope of UKAS accreditation. The results presented are the only acceptable test results of the sample data supplied. Caution, this is an extract only and the complete test results are available on request. Specro International Ltd. is not responsible for any damage or loss of equipment or assets. All tests carried out in accordance with in house documented procedures. Results are not to be reproduced without the written permission of Specro International Ltd.											
By authority of Richard McNaught, Operations Manager, UKAS accredited testing laboratory No. 0209. Specro and Jet-Care are registered trademarks and are used under licence by Specro Oil AS and Jet-Care International Inc. Copyright © Specro International Ltd. 2021 Specro Oil Analysis V.2.0.0 - Specro-Oil-System-Processor-0.020918.pdf											
APPROVED BY: SARAH MCNAUL SENIOR LABORATORY TECHNICIAN Specro Hatchetfield Place Farnham Road Farnham Surrey GU10 4AB UK T: +44 (0) 1252 740000 W: www.specro-oil.com											
← based on agreed or OEM specified limits values											

OIL ANALYSIS REPORT

<p>Customer Name</p> <p>For the Attention of</p> <p>Laboratory Report Reference</p> <p>Sample Report Date</p> <p>Receipt Date</p> <p>Sample Date \$</p> <p>Sampling Point \$</p>	<p>Equipment Information</p> <p>Vessel \$</p> <p>Division \$</p> <p>Manufacturer \$</p> <p>Model \$</p> <p>Serial Number \$</p> <p>Customer Reference \$</p> <p>Unserviceable Code</p> <p>Oil Grade \$</p> <p>Unit Life \$</p> <p>Oil Life \$</p>	<p>EMILY WILHELM</p> <p>Stern Thruster Gear</p> <p>Shell Omala 150</p>
--	---	--


Opinions and interpretations included in this report are outside the scope of URAS accreditation. The results are based on the analysis of the sample data supplied. Samples are taken at the discretion of the customer. Results are not necessarily representative of the condition of the vessel. All tests carried out in accordance with in house documented methods.

By authority of Richard McInair, Operations Manager, UKAS accredited testing laboratory No. 0269. Spectro and Oil-Care are registered trademarks and are sold under license by Spectro Oil AG and Ave-Care International Inc. Copyright © Police International Ltd 2022. W. +44 (0) 2256 548 144 | E. info@spectro-oil.com

APPROVED: UK: BARRIE MCINAIN
SENIOR LABORATORY TECHNICIAN

Spectro | Hatchfield Place | Farnham Road | Farnham | GU10 4JL | UK
T: +44 (0) 2256 548 144 | E: info@spectro-oil.com

Page 4/5




IDEA
DATA SOLUTIONS

A strategic partnership between Spectro | Jet-Care and IDEA Data Solutions provides enhanced options to the IDEA YACHT management solution, allowing customers' automatic visibility of their laboratory analysis results in the IDEA software.

Customers can submit a request to send a fluid or debris sample via IDEA YACHT by using the Spectro | Jet-Care sample kit unique number to complete the online label and send the sample in the usual way to their chosen laboratory. On completion of the laboratory analysis they will receive their analysis report via email as well as be able to access the results automatically from the software. This allows full tracking of the sample progress, as well as building a history of report analyses within a single archive.

In addition, Spectro | Jet-Care and IDEA will continue to review potential future enhancements to bring efficiencies to the day to day management of yachts.



SPECTRO®
JET-CARE®

SPECTRO
Odiham | Hampshire | UK
T +44 (0) 1256 704000
enquiries@spectro-oil.com

JET-CARE
Cedar Knolls | NJ | USA
T +1 973 292 9597
inquiries@jet-care.com

SPECTRO OIL AG
Kaiseraugst | Switzerland
T +41 (0) 61 815 90 20
enquiries@spectro-oil.com

spectro-oil.com | jet-care.com

'Spectro' and 'Jet-Care' are registered trademarks and used under licence by Spectro Oil AG and Jet-Care International Inc. Copyright © Palace International Ltd. 2024