



# EpoxyEx

## Epoxy resin remover

Industriestrasse 3 | CH-9602 Bazenhaid | phone +41 (0)71 931 70 30 | fax +41 (0)71 931 44 54 | www.pramol.com



**Dissolves and removes residues of epoxy resin joint material and other plastic-containing materials:**

Ceramics - glass mosaic - porcelain stoneware tiles - natural stone



- Spread over the surface to be cleaned and allow to act for **at least 15 minutes**.
- If necessary, make it more liquid with a little additional water, **material should not dry out**.
- Afterwards, work off mechanically or manually with a pad or brush and dissolve the material with water. **Rinse with sufficient water**.
- The fresher the soiling, the easier it is to remove.



**Use pure.  
Shake well before use!**

# EpoxyEx

**Epoxy resin remover**

Application area	Processing	Container size	Art. No.	pH-values	Dosage
		1 kg 5 kg	29695.00101 29695.00134	Application solution 12	Use pure

254 EN/6pr

**PRAMOL-CHEMIE AG**

Industriestrasse 3  
CH-9602 Bazenheid

+41 (0)71 931 70 30  
www.pramol.com

